



MOVE FORWARD. ALWAYS.™

DAYCO TENSIO METER TEST CODE LIST

DAYCO PART#	DAYCO ARTICLE	TEST CODE
94002	124RHP254	1351826
94003	106RP190H	0921319
94005	117RHX254	1272028
94006	120RHX190H	0871319
94007	138R254	1132028
94012	083RHX190H	0871319
94017	121RX180	0751318
94018	138R180	0761318
94019	163RHX254H	1162028
94020	057R190-W	0791319
94026	149RH300	1302433
94028	126R254	1122028
94036	104RP254H	1221826
94040	137RHX300	1502433
94047	110RP170	0911217
94050	130RP254	1362028
94052	120R150	0631115
94053	116R190	0801319
94054	146R190	0801319
94055	100R170	0721217
94056	084R190	0801319
94057	123R190	0801319
94058	120R180	0761318
94059	094RX190	0801319
94063	095R190	0801319
94064	148R190	0801319
94067	055R127	0530913
94068	121RHP+200H	0961420
94070	120R190	0811318
94071	113R190	0801319
94072	097RX254	1071826
94075	088R190	0801319
94076	101RP170	0901217
94078	111RP170	0911217



MOVE FORWARD. ALWAYS.™

DAYCO TENSIO METER TEST CODE LIST

DAYCO PART#	DAYCO ARTICLE	TEST CODE
94079	142RX254	1121826
94080	111RP200	1071420
94081	087RHX340	1592737
94082	069RX190	0811319
94083	134RHX300	1502433
94084	151RP254	1362028
94085	106R190	0801319
94086	121RX150	0631015
94087	098R190	0801319
94088	139R180	0761318
94089	111RP190	1011319
94090	075RH200	1011622
94091	091R190	0801319
94092	119RHX254	1272028
94093	111R190	0801319
94094	139R254	1132028
94095	101R254	1071826
94096	109R190	0801319
94097	111R254	1081826
94099	141R254	1122028
94103	089R190	0801319
94104	122RHX254C	1272028
94106	118RX150	0631115
94107	169RHP+254	1351826
94108	078RP190	1011319
94110	119RX190	0801319
94112	092RP+198H	0961420
94115	102RP190	1021319
94116	109RP190	1011319
94118	112RP190	1011319
94119	119RHPR190	0981319
94120	125RP190H	0921319
94121	098RHPR190	0991319
94122	142RX180	0761318



MOVE FORWARD. ALWAYS.™

DAYCO TENSIO METER TEST CODE LIST

DAYCO PART#	DAYCO ARTICLE	TEST CODE
94123	109RP220H	1061522
94125	102R190	0801319
94126	124RP190	1021319
94129	123RHX190H	0871319
94131	178RHP+254H	1191826
94135	192RP280H	1352028
94136	123RHP+200H	0961420
94137	129RP240H	1161724
94138	173RHP220	1161824
94139	127RPR254	1171826
94140	098R170	0721217
94141	126RP240	1281724
94142	123RHP+240H	1151724
94144	110RP254H	1281826
94145	108RX190	0811319
94146	123RH254	1111927
94147	089RP190H	0901319
94148	153RHX254	1272028
94150	163STP8M267MIS	1441927
94151	153RHX300	1502433
94152	149RP254H1	1231826
94154	107RHP+216H	1041522
94155	133RP254	1361826
94156	124RP240H	1161724
94157	143RP254	1362028
94158	106RP240H	1161724
94160	153RP254	1362028
94162	133RP240	1291724
94163	107RP240H	1161724
94164	133RR190	0811319
94165	173STP300H	1472130
94166	137STP254H	1251826
94167	163STP267H	1321927
94168	133RR220	0951824



MOVE FORWARD. ALWAYS.™

DAYCO TENSIO METER TEST CODE LIST

DAYCO PART#	DAYCO ARTICLE	TEST CODE
94169	104RP170/1	0911217
94170	133RR254	1091826
94174	093R190	0801319
94175	122RHX190H	0871319
94176	143R190	0801319
94177	055SHX127H-W	0570913
94179	108RP240H	1161724
94180	143R254	1121319
94181	101RP240H	1151724
94185	125RP200	1071420
94186	104RP170	0911217
94187	114RP+170H	0821217
94189	164RP230	1231623
94191	144RP254H	1222028
94192	097RX190	0801319
94193	104RX150	0631015
94195	065RHP+127H	0620913
94196	148RP254	1352028
94197	159RHP+254H	1201826
94198	142STP190	0981319
94199	054R190	0861319
94200	144R190	0801319
94201	211RHP+300	1592130
94201	211RHP+320H	1592130
94202	113RP190H	0911319
94205	104R254	1071826
94206	145RHP+220H	1051522
94208	125RP260H	1251826
94209	165RHP220	1171824
94210	107RHP+220H	1051522
94211	095RP170H	0921217
94212	070RP160H	0781116
94213	113RP240H	1151724
94215	209STP340H	1662736



MOVE FORWARD. ALWAYS.™

DAYCO TENSIO METER TEST CODE LIST

DAYCO PART#	DAYCO ARTICLE	TEST CODE
94216	092RP220H	1061522
94219	145R180	0801318
94220	105R190	0801319
94221	097RP+254H	1221826
94222	115RX190	0801319
94223	076RHX190	0951319
94224	136RP254H	1212028
94226	116RP190	1011319
94227	106RP220	1181522
94229	146RP240	1281926
94231	126RR254	1092028
94232	152RHX300	1512433
94233	117RHX254H	1162028
94234	097RP+198H	0951420
94234	097RP+198H	1001420
94235	117RP+190	0921319
94236	104RX170	0711217
94237	107RP200	1071622
94238	157RP230	1231623
94240	147RP240	1291926
94241	127RP254	1362028
94243	157RP320	1712635
94244	057RR190-W	0811319
94245	117R150	0641217
94246	107R190	0801319
94247	127R254	1121927
94248	128RPR254	1161826
94249	138RHPN150	0781115
94250	168RHPN180	0941318
94251	168RHPN220	1151724
94252	128RHP254	1352028
94253	098RH190	0861521
94254	118RH318	1392535
94255	108RP150	0801115



MOVE FORWARD. ALWAYS.™

DAYCO TENSIO METER TEST CODE LIST

DAYCO PART#	DAYCO ARTICLE	TEST CODE
94256	108RP170H	0821217
94257	138RPV285	2392331
94258	118RP190	1011319
94261	107RHP+190H	0911319
94263	141RP240	1281724
94265	149RP254H	1232028
94266	127RP254H	1221826
94268	163RHX254	1272028
94269	122RP240H	1151724
94285	121RHP+290H	1392029
94287	135RHP+254H	1221826
94289	117RHP+210H	1001521
94290	121RHP+210H	1001521
94295	077RHX210	1051623
94296	093RP+254H	1231826
94298	107RHP+190	1001319
94299	110RHP+190	1001319
94300	110RP210H	1011521
94302	124RX180	0801318
94303	128STP190	0981319
94303	128STP190C	0981319
94304	137RHX254	1262028
94305	143RH300H	1202433
94306	146RHP+190	1001319
94309	155RHP+190H	0911319
94316	129RP310H	1502234
94317	095RP+190H	0921319
94319	104RP240H	1161724
94323	094RP254H	1232028
94324	097RP+216H	1041522
94326	131RP+254H	1231826
94327	173RHP254	1342028
94328	148RP254H	1232028
94329	118RP190H	0921319



MOVE FORWARD. ALWAYS.™

DAYCO TENSIO METER TEST CODE LIST

DAYCO PART#	DAYCO ARTICLE	TEST CODE
94330	116RP190H	0911319
94331	101RP170H	0821217
94332	119RHX320H	1612635
94332	119SHX320H	1612635
94334	127RHP+240H	1151724
94335	192STP300H	1462130
94337	257RHP+320H	1502232
94338	119RP+254H	1231826
94340	111RP254H	1221826
94345	151STP190H	0941319
94349	091RP190H	0911319
94352	128RHP+260H	1251826
94353	104RP150	0801115
94356	110RPDD140H	0801014
94357	104RP170H	0821217
94358	119RP190H	0921319
94359	164STP254H	1242028
94360	115RP190	1011319
94361	148RP254H1	1231826
94363	103RHP+190	0971319
94366	090R190	0801319
94367	063RX190	0801319
94368	109RHP+160	0851116
94370	219RP254H	1222028
94371	143RHP+230H	1111623
94373	110R254	1081826
94374	062RH190	0861319
94376	068RX150	0631015
94377	110R180	0761318
94378	099RHX190	0941521
94379	116RHDN200H	0991622
94385	112RX190	0811319
94386	071RPV178	481420
94386	071RPV178	1481420



MOVE FORWARD. ALWAYS.™

DAYCO TENSIO METER TEST CODE LIST

DAYCO PART#	DAYCO ARTICLE	TEST CODE
94387	121RP200	1071420
94389	046R190	0801319
94390	121RHP+240H	1151724
94392	083RX190	0811319
94394	119RP254H	1231826
94397	168RHP+254H	1191826
94398	108RP254H	1221826
94399	126RHP+230H	1101623
94402	095RP254H	1231826
94403	130RHDN254H	1252028
94404	080RHX210H	0961623
94405	124RHX265H	1212129
94406	149RHX300H	1372433
94407	152STP254	1312028
94408	162STP300H	1312433
94409	119RHX320	1612635
94410	143RP210H	1011521
94411	134RP254C	1361826
94413	108RP320H	1552635
94414	170RHP220	1161824
94415	170RHP254	1342028
94416	135RHX254	1272028
94417	239STP254H	1241826
94418	103R190	0801319
94419	044R170	0721217
94422	122RX190	0801319
94423	134RX254	1061826
94426	119RX190C	0801319
94427	119SHPR190H	0951319
94433	127RP240H	1161724
94434	096RHX254	1271826
94435	097RHDD150H	0801115
94436	130RH254	1112028
94439	152RHDS300	1542433



MOVE FORWARD. ALWAYS.™

DAYCO TENSIO METER TEST CODE LIST

DAYCO PART#	DAYCO ARTICLE	TEST CODE
94444	092RHX190H	0871319
94445	169RHP+254H	1201826
94451	103RP254H	1221826
94453	143RH300	1312433
94460	112RP240H	1151724
94461	112RP290H	1402029
94463	124RP290H	1412029
94464	133RP254H	1221826
94465	193STP360H	1762636
94467	123RP+190H	0911319
94468	123RP+290H	1392029
94469	124RP260H	1251826
94470	151STP190	0981319
94471	223STP320H	1562232
94472	103RHP+160H	0771116
94480	153RHDS300	1542433
94481	194R220	0971522
94484	174RP+280H	1352028
94485	096R254	1071826
94486	220RHP220	1161522
94487	225RHP220	1171522
94488	167RP230H	1111623
94489	109RP+300H	1452433
94491	173RHP180H	0861318
94492	145RHP+216H	1031522
94494	156RHP+290H	1392029
94495	187RHP+320H	1502332
94500	099RHP+160	0851116
94510	117RHP+290H	1392029
94513	118RX190	0801319
94522	099RHP+190H	0911319
94523	077RHX200	1001522
94524	177RP254H	1222028
94527	127RP190H	0921319



MOVE FORWARD. ALWAYS.™

DAYCO TENSIO METER TEST CODE LIST

DAYCO PART#	DAYCO ARTICLE	TEST CODE
94528	103RP190H	0921521
94530	089RP254H	1231826
94532	113RP170H	0821217
94534	126RP260H	1251826
94535	143RHP+254H	1221826
94536	146RP280H	1352028
94537	150RP290H	1442029
94540	085RHDN230H	1141825
94541	162STP254H	1252028
94547	136RHP150	0791119
94554	095RHX190	0951521
94555	106RP+DD190H	1121319
94556	134RP254H	1221826
94557	141RP280H	1352231
94564	094RX190H	0751319
94566	118RP+300H	1452433
94567	134RHPN180H	0891318
94568	110RPDD180H	1031318
94582	179STP320H	1562332
94584	299STP300H	1462130
94588	158RHPN254H	1221826
94589	167RHPN240H	1181724
94590	168RHPN240H	1181724
94591	130ROLD150H	0721115
94592	193RHPN240H	1191926
94593	193RHPN240H1	1191926
94594	108RX150H	0591115
94596	265RHP+320H	1502232
94597	226RHP+300H	1422130
94600	148RP230H	1111623
94602	099RHP+254	1281825
94604	151STP254H	1241826
94605	136RHX254H	1172028
94608	137RHX230H	1051825



MOVE FORWARD. ALWAYS.™

DAYCO TENSIO METER TEST CODE LIST

DAYCO PART#	DAYCO ARTICLE	TEST CODE
94616	154RHP+220H	1061522
94618	103RP240H	1161724
94621	281RHP+300H	1412130
94625	138RH254	1141826
94637	133STP190	0981319
94638	103RP240	1281724
94647	259P8S320H	1632232
94648	078RP8M200H	0961421
94650	111RP170H	0821217
94651	141RHX300H	1372433
94652	147STP254H	1251826
94655	157RP254H	1222028
94656	107RHP+180H	0861218
94657	120RHX254H	1161826
94658	163RP254H	1222028
94659	169STP240H	1181724
94660	105RP220H	1061522
94662	146STP200H	0981420
94664	154RHDS300H	1552433
94665	155RHP+240H	1151724
94668	092R190	0801319
94670	168RHPN220H	1091724
94671	117RP+220H	1061522
94673	132RP230H	1111623
94674	163RHPN240H	1181726
94675	166RHPN240H	1181724
94676	113RP254H	1231826
94679	146RHP+254H	1221826
94680	152STP254H	1241826
94687	137STP190H	0931319
94688	116RHDN220H	1091824
94689	147STP190H	0941319
94691	063RHP150H	0711015
94692	136RP254H1	1212028



MOVE FORWARD. ALWAYS.™

DAYCO TENSIO METER TEST CODE LIST

DAYCO PART#	DAYCO ARTICLE	TEST CODE
94693	135STP190H	0931319
94695	122RP190H	0911319
94696	085RHDN220H	1091724
94697	078RP+220H	1061724
94698	112RP+280H	1352231
94702	228RHP+320H	1502232
94709	124P8S220H	1121522
94710	131RHPN170H	0841217
94711	134RHPN170H	0851217
94713	190RHPN240H	1181926
94714	136RP+254H	1231826
94715	126RHPDD150H	0881115
94718	146R254	1091825
94719	176RP+280H	1352028
94720	058RP+220H	1071522
94721	125RHP+220H	1071522
94723	124RX180H	0711318
94724	114RP+254H	1221826
94725	117RP+254H	1232028
94726	102RP250H	1222028
94727	107RHP+160H	0771116
94730	138STP230H	1131623
94731	104RX150H	0591015
94732	137RHX254H	1162028
94733	158RP320H	1542635
94734	083RP190H	0911319
94735	151RP290H	1402029
94736	153RP290H	1412029
94737	121RX180H	0711318
94738	111RP190/1	1011319
94740	147RP+320H	1552635
94741	127RP+254H	1221826
94742	130RHDN276H	1362230
94747	113RHP+254H	1221826



MOVE FORWARD. ALWAYS.™

DAYCO TENSIO METER TEST CODE LIST

DAYCO PART#	DAYCO ARTICLE	TEST CODE
94753	112RP+300H	1442433
94754	078RP+240H	1161826
94755	207RHX320H	1472534
94757	153RP260H	1262129
94758	145RP300H	1522433
94763	124RHP+260H	1251826
94764	154RHP+290H	1392029
94766	151RP300HT	1512433
94767	144RP230H	1111623
94768	135STP190	0931319
94769	176STP240H	1171926
94771	111RHP+290H	1392029
94772	153RP254H	1222028
94774	122RHX265H	1212129
94775	081RHX210H	0961623
94776	130STP200H	0981420
94777	150STP230H	1131623
94778	141RHX254H	1162028
94782	087RP170H	0821217
94783	152RHDS300H	1522433
94785	096RP170H	0921217
94785	096SP170H	0921217
94786	176RP280H	1472028
94787	162STP200H	0991420
94788	058STP8M170H	0841217
94789	142RP230H	1111623
94790	059RP220H	1051522
94791	101RP300H	1442433
94792	101RHP+200H	0971420
94801	129RP+254H	1231826
94807	195RHP+320H	1502332
94808	140RP+254H	1132028
94809	107RHP+254H	1211826
94810	153RHDS300H	1522433



MOVE FORWARD. ALWAYS.™

DAYCO TENSIO METER TEST CODE LIST

DAYCO PART#	DAYCO ARTICLE	TEST CODE
94812	113RHD250H	1241725
94817	095RP170H	0921217
94819	070RP180	0881318
94820	068RX190	0801319
94822	116RHP+290H	1392029
94823	152RP280H	1352028
94824	171STP240H	1171724
94825	225STP300H	1472130
94826	191STP320H	1562332
94827	143RHP+260H	1251826
94829	149RP240H	1161926
94830	149STP254H	1251826
94831	105RP254H	1222028
94832	122RP290H	1392029
94833	169STP200H	0981420
94835	253STP300H	1462130
94836	065STP127H	0620913
94837	173STP290H	1422029
94838	207RHP+320H	1512332
94839	087RHX240H	1101926
94840	141RP+254H	1232028
94841	149RP300H	1452433
94843	153STP250H	1241725
94846	091RP+200H	0971622
94847	132RP270H	1301927
94850	138RHPN150H	0741115
94853	097RP254H	1221826
94854	133RHP+254H	1221826
94856	197RHP+260H	1221826
94857	076RHX190H	0951521
94859	132STP190	0981319
94860	129P8S150H	0771115
94861	125P8S150H	0761115
94862	104RP170H/1	0821217



MOVE FORWARD. ALWAYS.™

DAYCO TENSIO METER TEST CODE LIST

DAYCO PART#	DAYCO ARTICLE	TEST CODE
94863	100RP170H	0821217
94864	201RHP+300H	1462130
94866	223RHP+270H	1311927
94869	123RHP+220H	1061522
94870	153RP270H	1302230
94872	128RP270H	1301927
94876	054RP170H	0821217
94884	117RP300HT	1532433
94885	120RP300HT	1542433
94890	122RHX260H	1192129
94893	103RP220H	1061522
94896	111RP254H/1	1222028
94897	207RHX300HT	1542433
94904	109RHP+250H	1201725
94905	153RP254H/1	1222028
94906	145RHP+260H	1251826
94908	089RP+250H	1232027
94909	137RP+254H	1231826
94910	095RP+234H	1131624
94911	146RP+254H	1232028
94919	110STP220H	1131522
94922	114RP+300H	1452433
94923	144RP+254H	1222028
94924	178RP+300H	1452433
94925	092RP250H	1222027
94926	143RP254H	1231826
94927	151RP254/1	1362028
94928	153RP254/1	1362028
94929	153RP254H/2	1222028
94930	134RP270H	1301927
94931	089RP210H	1011521
94932	104RP220H	1061824
94933	111RHP+254H	1221826
94934	130RHDN254HT	1282028



MOVE FORWARD. ALWAYS.™

DAYCO TENSIO METER TEST CODE LIST

DAYCO PART#	DAYCO ARTICLE	TEST CODE
94935	130RHDN276HT	1392230
94936	178RP250HT	1262028
94938	137STP220H	1091522
94939	132RP260H	1252129
94940	126RP270H	1301927
94941	137RHX250HT	1282028
94942	141RHX250HT	1282028
94943	153RP260HT	1312129
94944	123RP270H	1302230
94945	168STP240H	1181724
94946	131RP+270H	1331927
94947	131RP+250HT	1262028
94949	152RP290HT	1462332
94950	129P8S220H	1121522
94951	146RP280HT	1642028
94952	175STP290H	1412029
94953	201RHP+320H	1502232
94954	153RHP+280H	1372029
94955	097RP190H	0921319
94956	135RP+254H	1232028
94957	134RP254H2	1221826
94958	198RHPN240H	1191926
94959	143RP+254H	1232028
94962	178RP+300HT	1512433
94966	092RSP250	1382028
94968	123RP280H	1352331
94969	129RP+250HT	1352028
94970	141RP300HT	1592433
94971	145STP230HT	1251826
94972	159RHP+290H	1422029
94973	083RP240HT	1261926
94974	146STP240HT	1301724
94975	116RP+254H	1222028
94976	199RHPL240HT	1281926



MOVE FORWARD. ALWAYS.™

DAYCO TENSIO METER TEST CODE LIST

DAYCO PART#	DAYCO ARTICLE	TEST CODE
94977	125P8S220H	1121522
94978	126RP270HT	1371927
94979	148STP230HT	1191623
94980	097RP250H	1192028
94981	122RP200H	0961420
94982	133RP260H	1262129
94983	091RHDN250HT	1082028
94984	111RHPN280HT	1412028
94985	091RP+280HT	1362028
94986	195RP+290HT	1472433
94987	190RHPN240HT	1311926
94988	141STP250HT	1251825
94989	085RP+200HT	1011622
94990	132RHP+250	1222028
94991	153RP270HT	1362230
94992	153RP+270H/1	1312230
94993	281RHP+300H	1412130
94994	197RHP+200H	0961622
94995	281RHP+300H/1	1412130
94996	135RP+250HT	1262028
94997	132RP270HT	1361927
94998	085RHDN220	1091724
94999	116RHDN200	0991622
94999	116RHDN220	0991824
941001	137RHX254HDT	1282028
941002	123CYH220H	1061522
941003	136RP254	1212028
941004	137RHX230HT	1231825
941006	123RP270HT	1382230
941008	141RHX260HT	1402129
941009	091RP+200HT	1001420
941010	148STP200H	0991420
941011	281SHP+300HT	1492130
941011	281RHP+300HT	1492130



MOVE FORWARD. ALWAYS.™

DAYCO TENSIO METER TEST CODE LIST

DAYCO PART#	DAYCO ARTICLE	TEST CODE
941012	104RP300H	1452433
941013	130STP200HT	1001420
941014	058STP170HT	0841217
941015	171STP240	1171724
941017	182RHD280	1512028
941018	137RP+250HT	1262028
941019	089RP+250HT	1252028
941020	151RP254H	1362028
941021	151RP254H/1	1362028
941023	132RP280H	1352231
941024	054RP5M120HT	0440812
941025	127RP254H/1	1271825
941026	135RP+400HT	2013244
941026	135RP+400HT	2013244
941027	103RP265H	1292129
941028	153RP300HT	1782433
941029	070RP180HT	1141420
941030	093RP170H	0911217
941031	151RP220HT	1451824
941032	160RP300HT	1822433
941033	160RP250HT	1462028
941034	150RP300HT	1752433
941035	194RHPL240HT	1351926
941038	141RHX254HDT	1302028
941039	144RHP+254H	1251825
941040	082RP+200HT	1021622
941041	195RP+300HT	1452433
941042	082RP+200HT	1021622
941043	154RP254H	1272028
941044	198RHPN240HT	1281926
941045	116RP+250HT	1302028
941047	281STP300H	1412130
941048	141RP+250HT	1242028
941049	117RP+220HT	1211522



MOVE FORWARD. ALWAYS.™

DAYCO TENSIO METER TEST CODE LIST

DAYCO PART#	DAYCO ARTICLE	TEST CODE
941050	124P8S220HT	1141522
941051	137RP220H	1091522
941052	118RP+250HT	1272028
941053	144RP+250HK	1252028
941055	193RHPL240HT	1291926
941056	086STP300HT	1532433
941057	151RP220H	1161824
941060	163RP7M200HT	1051622
941071	137RP220HT	1081824
941072	113RP170HT	0861217
941073	072RP190H	0931319
941080	046RP+100HT	052710
941081	081STP5M100HT	035710
941082	067RP5M120HT	072812
941083	220RHP280HT	1392231
941094	087STP5M100HT	0320710
941117	137RP+250HK	1182231
941136	116RP+168HT	911217
941137	103RP+160HT	911116